

Divided Pouch Activation Instructions

Locate and firmly grasp the pull tabs on either side of the pouch. Pull the tabs to separate the dividing membrane seal between the media chambers.



Attention:
Pouch will separate to about 2 ½" from edge.
Be careful not to force opening beyond this to prevent tearing.



Pool media into bottom of the pouch –
Perforations should be on top – refer to orientation
arrows on label.

Shake to blend media inside pouch



Position the pouch so that the perforations are
not obstructed. Place or hang in treatment
area as directed.



After treatment is completed, discard in outdoor trash.